



Introduction: the master brake cylinder replacement set, must be installed after having bled the hydraulic system. Also before the installation all the O-rings must be greased for a clipping free fixing.

Sequences:

- Unscrew the hexagonal cap (point 9) and extract all the internal parts from the master brake cylinder body (pos 12)
- Remove the spring pin (point 11) and remove the axle spring (point 10)
- Replace the two O-rings that are inside the hexagonal cap (point 5 and 2)
- Unscrew the closing ring bush (point 8) from the cylinder axle and pull out the piston (point 6)
- Replace the O-ring (point 4) on the piston (point 6)
- Replace the O-ring (point 3) on the cylinder axle.
- Insert the piston (point 6) in the new cylinder axle (point 1), with its dedicated spring (point 7) and tighten firmly through the locking bush (point 8)
- Insert the assembled parts into the master brake cylinder body (point 12) and screw in, the hexagonal cap (point 9)
- insert the spring (point 10) into the cylinder axle (point 1) and block it using the spring pin (point 11)

Check the correct functioning of the master brake cylinder making pressure with your hands, install and fill the system with MINERAL oil, perform the bleeding according to our specification